

Tankless Reverse Osmosis System Filter Replacement


#1 Pre-Filter (Black)

#2 Reverse Osmosis Membrane (Blue)

THIS PACKAGE CONTAINS THE PRE-FILTER AND REVERSE OSMOSIS
MEMBRANE FOR YOUR TANKLESS REVERSE OSMOSIS SYSTEM. PLEASE FOLLOW
THE STEPS BELOW TO REPLACE YOUR FILTERS.


Stage 1: Filter Replacement Set Up


NOTE: Start by clearing the area around your Reverse Osmosis System under the sink and ensure you have enough room to access the filters through the magnetic top cover of your system.





Open the faucet on the countertop to release all pressure to the Tankless Reverse Osmosis System, and leave the faucet open until you have replaced the required filters.







For more information please scan the QR code or visit **enercare.ca/tanklessfilters**



Tankless Reverse Osmosis System Filter Replacement


#1 Pre-Filter (Black)


#2 Reverse Osmosis Membrane (Blue)


THIS PACKAGE CONTAINS THE PRE-FILTER AND REVERSE OSMOSIS
MEMBRANE FOR YOUR TANKLESS REVERSE OSMOSIS SYSTEM. PLEASE FOLLOW
THE STEPS BELOW TO REPLACE YOUR FILTERS.


Stage 2: Replacing #1 Pre-Filter and #2 Reverse Osmosis Membrane

NOTE: Your Pre-Filter and Reverse Osmosis Membrane will arrive in an encasing that is designed to make the filter change process as simple as possible.













Tankless Reverse Osmosis System Filter Replacement

#1 Pre-Filter (Black)

#2 Reverse Osmosis Membrane (Blue)

THIS PACKAGE CONTAINS THE PRE-FILTER AND REVERSE OSMOSIS
MEMBRANE FOR YOUR TANKLESS REVERSE OSMOSIS SYSTEM. PLEASE FOLLOW
THE STEPS BELOW TO REPLACE YOUR FILTERS.

Stage 3: Pressure Test, Purge, and Filter Reset

NOTE: After reassembling the Tankless Reverse Osmosis System, follow the steps below to perform a pressure test, purge and filter reset before use.



Open the main shutoff valve on the cold water supply line by turning it clockwise.



2

Let the water run out of the countertop faucet for 10-15 minutes forward for the Reverse Osmosis and another 10 -15 minutes backward for the purified side of the faucet.





To reset the Pre-Filter and RO on Model A:

- a) Hold the "RESET" button for 3 seconds until you hear a beep then release.
- b) Use the "RESET" button to select "PCT" (for Pre-Filter)
- c) Press and hold the "RESET" button for 3 seconds to reset filter on the unit.
- d) To reset the RO filter, repeat all the steps and select "RO" at step b above. Once both filters have been reset, the unit is ready to use.





To reset the Pre-Filter and RO on **Model B**:

- a) Hold the "RESET" button (red arrow "A") for 3 seconds until you hear a beep then release
- b) Use the "SELECT" button (red arrow "B") to select "PCT" (for Pre-Filter)
- c) Press and hold the "RESET" button for 3 seconds to reset filter on the unit.
- d) To reset the RO filter, repeat all the steps and select "RO" at step b above. Once both filters have been reset, the unit is ready to use.





For more information please scan the QR code or visit **enercare.ca/tanklessfilters**

PLEASE NOTE: You will be solely liable for any damage relating to such replacement, including the failure to follow the instructions and/or properly replace the filter/cartridge. If you require assistance, please contact Enercare to obtain a quote to complete such replacement for you.